


20 208 002 EUROSTYLE COSMOPOLITAN 3-HOLE WASH-BASIN MIXER S-SIZE




SPARE PARTS, November 2021 – now

- 1: Handle pair (Spare part-nr. 48309000)
- 2: Ceramic headpart, 1/2" (Spare part-nr. 45882000)
- 2.1: O-ring Ø18,2 x Ø1,7 (Spare part-nr. 0392400M)
- 3: Ceramic headpart, 1/2" (Spare part-nr. 45883000)
- 3.1: O-ring Ø18,2 x Ø1,7 (Spare part-nr. 0392400M)
- 4: Coupling nut 1/2" (Spare part-nr. 1290100M)
- 4.1: Fibre seal dia. Ø18,5 x Ø12 x 2 (Spare part-nr. 0138900M)
- 5: Mousseur (Spare part-nr. 13929000)
- 6: Pop-up rod (Spare part-nr. 46739000)
- 7: Connection hose (Spare part-nr. 46255000)
- 8: Base plate (Spare part-nr. 48165000)
- 9: Shank mounting kit (Spare part-nr. 46671000)
- 10: Waste set 1 1/4" (Spare part-nr. 28910000)
- 10.1: Plug (Spare part-nr. 07182000)
- 10.2: Eccentric rod (Spare part-nr. 07052000)
- 11: Mounting wrench (Spare part-nr. 19017000)*
- 12: Eccentric rod (Spare part-nr. 07341000)*
- 13: Coupling nut 1/2" x 14,5 mm (Spare part-nr. 1290200M)*

* Optional accessories

20 208 002 EUROSTYLE COSMOPOLITAN 3-HOLE WASH-BASIN MIXER S-SIZE




SPARE PARTS, July 2019 – November 2021

- 1: Handle pair (Spare part-nr. 48309000)
- 2: Ceramic headpart, 1/2" (Spare part-nr. 45882000)
- 2.1: O-ring Ø18,2 x Ø1,7 (Spare part-nr. 0392400M)
- 3: Ceramic headpart, 1/2" (Spare part-nr. 45883000)
- 3.1: O-ring Ø18,2 x Ø1,7 (Spare part-nr. 0392400M)
- 4: Coupling nut 1/2" (Spare part-nr. 1290100M)
- 4.1: Fibre seal dia. Ø18,5 x Ø12 x 2 (Spare part-nr. 0138900M)
- 5: Mousseur (Spare part-nr. 13929000)
- 6: Pop-up rod (Spare part-nr. 46739000)
- 7: Connection hose (Spare part-nr. 46255000)
- 8: Shank mounting kit (Spare part-nr. 46671000)
- 9: Waste set 1 1/4" (Spare part-nr. 28910000)
- 9.1: Plug (Spare part-nr. 07182000)
- 9.2: Eccentric rod (Spare part-nr. 07052000)
- 10: Mounting wrench (Spare part-nr. 19017000)*
- 11: Eccentric rod (Spare part-nr. 07341000)*
- 12: Coupling nut 1/2" x 14.5 mm (Spare part-nr. 1290200M)*

* Optional accessories

20 208 002 EUROSTYLE COSMOPOLITAN 3-HOLE WASH-BASIN MIXER S-SIZE



SPARE PARTS, March 2010 – July 2019

- 1: Handle Eurostyle Cosmopolitan red (Spare part-nr. 48069000)
 - 2: Handle Eurostyle Cosmopolitan blue (Spare part-nr. 48068000)
 - 3: Ceramic headpart, 1/2" (Spare part-nr. 45882000)
 - 3.1: O-ring Ø18,2 x Ø1,7 (Spare part-nr. 0392400M)
 - 4: Ceramic headpart, 1/2" (Spare part-nr. 45883000)
 - 4.1: O-ring Ø18,2 x Ø1,7 (Spare part-nr. 0392400M)
 - 5: Coupling nut 1/2" (Spare part-nr. 1290100M)
 - 5.1: Fibre seal dia. Ø18.5 x Ø12 x 2 (Spare part-nr. 0138900M)
 - 6: Mousseur (Spare part-nr. 13929000)
 - 7: Pop-up rod (Spare part-nr. 46739000)
 - 8: Connection hose (Spare part-nr. 46255000)
 - 9: Shank mounting kit (Spare part-nr. 46671000)
 - 10: Waste set 1 1/4" (Spare part-nr. 28910000)
 - 10.1: Plug (Spare part-nr. 07182000)
 - 10.2: Eccentric rod (Spare part-nr. 07052000)
 - 11: Mounting wrench (Spare part-nr. 19017000)*
- * Optional accessories